

SLY

SY 075..ES

SY 071..ES

SY 070..


SY 075..

SY 071..

SY 130..


SY 135..

SY 131..




1


Montaggio Assembly




$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX




OK

2
a


075ES 071ES
071 070 075
131 130 135



b






c




075ES
070 075
130 135

C

075ES 071ES
071 070 075
131 130 135




d



F






Funzionamento
Working

075 ES
071 ES







Manutenzione
Service




S Sostituzione Cartuccia How to replace Cartridge

075ES 071ES
071 070 075
081 080 085
131 130 135



075ES 071ES
071 070 075
081 080 085
131 130 135



b Sostituzione Aeratore How to replace Aerator

c Sostituzione Snodo How to replace Joint

131 130 135

